

AccuFit®

6.5 LB Convertible Kitchen Scale User's Guide



Model MS-6040



Measurement Ltd., Inc.
www.measurement-ltd.com

Our authorized service center address:

11751 Rock Landing Drive
Suite H-7, Newport News
VA 23606

Attn: Customer Service

Power

The scale requires 1 x 3V replaceable Lithium battery CR2032. You can open the battery cover at bottom of the scale and install the battery.

Operation

- Place container on the scale platform if needed before starting.
- Press "ON/TARE" button on the front panel.



- Wait until "0" or "0.0" appears on the display.



- Press the "KG/LB" button on the front cover to get the desired unit.
- Place the ingredient into the bowl or on the platform.
- Read the weight on the display.



Tare Function

The "TARE" allows the display to zero-set after placing a container on the scale. This feature allows you to get the net weight of the contents.

Procedure

To tare the scale, press "ON/TARE" button, and repeat the above steps c, d, e and f.

Unit Function

This scale has two weight units, you can press the "KG/LB" button to change and the unit will be shown on the display.

Auto Power Off

Scale powers off automatically in about 60 seconds after reading is stable.

Manual Power Off

The scale allows manual power off. If you want to turn off the scale within 60 seconds, press the "ON/TARE" button and hold for 2 seconds.

Caution

Low Battery Warning Overload Warning Underload Warning



Warranty and Service

Measurement Ltd., Inc warrants this product against defects in material or workmanship for a period of 1 year from the date of purchase and agrees to replace it free of charge. This warranty does not cover damage resulting from misuse or abuse of the product. Should your product require service, you may send it back to Measurement Ltd., Inc for repair or replacement.