

AccuFit™

Pocket/Travel Scale

User's Guide



Measurement Ltd., Inc.
www.measurement-ltd.com

Our authorized service center address:

11751 Rock Landing Drive
Suite H-7, Newport News
VA 23606

Attn: Customer Service


Model MS-6290

Power

The scale requires 4 x AAA battery. You can open the battery cover at bottom of the scale and install 4 x AAA battery.

Operation

Press the "ON/TARE" button and wait for "0.0" to appear on the display. The scale is then ready for weighing. Place the object on the scale, the weight is shown on the display.



Tare Function

The "TARE" allows the display to zero-set after placing a container on the scale. This feature allows you to get the net weight of the contents.

Procedure

- Place an empty bowl or the cover tray on top of scale.
- Press the "ON/TARE" button and wait until "0.0" appears on the display.
- Pour materials to be weighted into container.
- Read the weight of materials on the display.

By repeating the above steps b,c and d, you may obtain the weight of different materials (e.g. precious stone and metals).

Caution: If scale exceeds capacity then "E" will be shown.

Unit Function

This scale has four weight units, you can press the "g/oz/dwt/ozt" button to change and the unit will be shown on the display.

Auto Power Off

The scale automatically turns itself off after a period of 60 seconds. To restart the scale simply presses "ON/OFF/TARE" button.

Manual Power Off

The scale allows manual power off. If you want to turn off the scale within 60 seconds, press the "ON/OFF/TARE" until the scale turns off.

Warranty and Service

Measurement Ltd., Inc warrants this product against defects in material or workmanship for a period of 1 year from the date of purchase and agrees to replace it free of charge. This warranty does not cover damage resulting from misuse or abuse of the product. Should your product require service, you may send it back to Measurement Ltd., Inc for repair or replacement.